



EZ6000 Arsenic Analyser As(III)

Kat. číslo produktu: EZ6000.XXXXXXXXXX
EUR Cena bez DPH: Kontaktujte nás

Trace metal analysis of dissolved Arsenic As(III) in water by online voltammetry

About the 6000 Series

The EZ6000 Series of Online Trace Metal Analysers are based on the technology of stripping voltammetry, a sensitive analytical technique that can be automated for the determination of trace levels of metals in water. For many metals the EZ6000 Series boasts limits of quantification in the low ppb range, comparing the technique favorably with AAS or ICP analysis.

Single, multiple and total parameter configurations

Several product sublines with a wealth of combinations are available for determination of trace metals, including the standard single parameter and multi-parameter configurations without digestion. Measurement of complexed or adsorbed metals is possible by means of the configurations with built-in digester. Combinations of metals depend on the choice of working electrode and the priority metals for your application.

Advanced features

The EZ6000 Series build upon tried and tested voltammetry technology used in many clean water applications, in an industrial mainframe with the following prime features:

- Excellent selectivity and sensitivity
- Built-in sample digestion unit (hot acid or UV)
- Smart automatic features
- Standard 4 - 20 mA signal output with alarm processing
- Communication ports supporting connectivity to Modbus
- Higher measuring ranges: internal sample dilution
- Multiple stream analysis

There are many additional options available. Please contact Hach for more details.

Technické údaje

Alarm: 1 x malfunctioning, 4 x user-configurable, max. 24 VDC/0.5 A, potential free contacts

Analógové výstupy:	Active 4 - 20 mA max. 500 Ohm load, standard 1, max. 8 (option)
Automatické čistenie:	Áno
Č. prúdov vzoriek:	1, 2, or 4
Certifikácia:	CE compliant / ETL certified
Chladicí voda:	Not required
Demineralised water:	For rinsing
Detekčný limit:	≤ 1 µg/L
Digitálne výstupy:	Optional: Modbus (TCP/IP, RS485)
Doba cyklu :	10 minutes
Earth connection:	Dry and clean earth pole with low impedance (< 1 Ohm) using an earth cable of > 2.5 mm²
Hmotnosť:	25 kg
Instrument air:	Dry and oil free according to ISA-S7.0.01-1996 quality standard for instrument air
Interferencie:	Iodide, organic matter, copper Cu(II) > 30 µg/L, iron Fe(III) >20 mg/L, various metals in mg/L levels may interfere. Fats, oil, proteins, surfactants and tar.
Kalibrácia:	Automatic, 2-point; frequency freely programmable
Kvalita vzorky:	Maximum particle size 100 µm, < 0.1 g/L; Turbidity < 50 NTU
Materiál:	Hinged part: Thermoform ABS, door: PMMA
	Wall section: Galvanised steel, powder coated
Metóda merania:	Stripping voltammetry using gold electrode
Model:	EZ6000
Napájanie:	100 - 240 VAC, 50/60 Hz
	Max. power consumption: 120 VA
Obsah balenia:	EZ6000 Arsenic Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets, 1 x Counter Electrode - Platina, 1 x Working Electrode - Gold, 1 x Reference Electrode - Ag/AgCl, 1 x empty 10L Reagent Container with Fittings (H2SO4 Solution) and 1 x empty 5L Reagent Container with Fittings (Buffer Solution) and 2 x empty 1L Reagent Container with Fittings (Reference Blank & Reference As Solution)
Odtok:	Atmospheric pressure, vented, min. Ø 32 mm
Parameter:	Arsenic, dissolved As(III)
Presnosť:	Better than 5% full scale range for standard test solutions
Reagent Requirements:	Keep between 10 - 30 °C
Rozmery (V x Š x H):	690 mm x 465 mm x 330 mm
Rozsah merania:	1 - 20 µg/L As
Rýchlosť prietoku vzorky:	100 - 300 mL/min
Teplota prostredia:	10 - 30 °C ±4 °C deviation at 5 - 95% relative humidity (non-condensing)
Teplota vzorky:	10 - 30 °C
Trieda ochrany:	Analyser cabinet: IP44 / Panel PC: IP65
Validation:	Automatic; frequency freely programmable
Vzorka: tlak:	By external overflow vessel
Záruka:	24 mesiacov

Obsah balenia

EZ6000 Arsenic Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets, 1 x Counter Electrode - Platina, 1 x Working Electrode - Gold, 1 x Reference Electrode - Ag/AgCl, 1 x empty 10L Reagent Container with Fittings (H2SO4 Solution) and 1 x empty 5L

Reagent Container with Fittings (Buffer Solution) and 2 x empty 1L Reagent Container with Fittings (Reference Blank & Reference As Solution)