



Be Right™



EZ1102 Ammonium Analyser (Berthelot Method)

Kat. číslo produkta:

EZ1102.XXXXXXXX

EUR Cena bez DPH:

Kontaktujte nás

Online colorimetric analysis of Ammonium in water

EZ1000 Ammonium Analysers achieve excellent precision and accuracy. At the heart of the colorimeter there is a compact photometer assembly developed especially for the EZ Series. Consumption of reagents is reduced by low volume analysis, yet high sensitivity is assured by a long optical path length. The limit of detection is in the low µg/L range.

Results you can rely on

Smart automatic features for calibration, validation, priming and cleaning are embedded in the controller software and contribute to analytical performance, maximised uptime and negligible operator intervention. Precision micropumps dose all reagents. Sample lines and analysis vessel are cleaned with demineralised water to eliminate cross contamination between samples. Electronic and wet-chemical part of the analyser are strictly separated. A transparent door allows for instant visual inspection of the wet part.

Flexibility that meets your needs

EZ Series Ammonium Analysers come in an attractive, ergonomic mainframe with a compact footprint. All hardware is controlled by the integrated industrial panel PC. The modular build allows for the analyser to match your application and operational needs.

- The standard measuring range can be narrowed by a different calibration range or extended via internal dilution options.
- Analogue and digital output options
- Multiple stream analysis for up to 8 sample streams

There are many additional options available. Please contact Hach for more details.

Technické údaje

Alarm:	1x malfunctioning, 4x user-configurable, max. 24 VDC/0.5 A, potential free contacts
Analógové výstupy:	Active 4 - 20 mA max. 500 Ohm load, standard 1, max. 8 (option)
Automatické čistenie:	Áno
Č. prúdov vzoriek:	1, 2, 4, or 8
Certifikácia:	CE compliant / ETL certified
Demineralised water:	For rinsing / dilution
Detekčný limit:	≤ 5 µg/L
Digitálne výstupy:	Optional: Modbus (TCP/IP, RS485)

Doba cyklu :	25 min (dilution + 5 min)
Earth connection:	Dry and clean earth pole with low impedance (< 1 Ohm) using an earth cable of > 2.5 mm ²
Hmotnosť:	25 kg
Instrument air:	Dry and oil free according to ISA-S7.0.01-1996 quality standard for instrument air
Interferencie:	Amino acids, hydrazine and urea. Large amounts of colour and turbidity interfere. Fats, oil, proteins, surfactants and tar.
Kalibrácia:	Automatic, 2-point; frequency freely programmable
Kvalita vzorky:	Maximum particle size 100 µm, < 0.1 g/L; Turbidity < 50 NTU
Materiál:	Hinged part: Thermoform ABS, door: PMMA Wall section: Galvanised steel, powder coated
Metóda merania:	Colorimetric measurement at 630 nm based on standard method APHA 3500-NH3 (Berthelot)
Model:	EZ1102
Napájanie:	100 - 240 VAC, 50/60 Hz Max. power consumption: 120 VA
Obsah balenia:	EZ1102 Ammonium (Berthelot Method) Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets and 2 x empty 2.5L Glass Reagent Containers with Fittings (for Reagent A & Reagent B Solution)
Odtok:	Atmospheric pressure, vented, min. Ø 32 mm
Parameter:	Ammonium
Presnosť:	Better than 2% full scale range for standard test solutions
Reagent Requirements:	Keep between 10 - 30 °C
Rozmery (V x Š x H):	690 mm x 465 mm x 330 mm
Rozsah merania:	0.025 - 1 mg/L NH ₄ Optional: 0.005 - 0.1 mg/L NH ₄ 0.01 - 0.25 mg/L NH ₄ 0.01 - 0.5 mg/L NH ₄ 0.2 - 4 mg/L NH ₄ (with internal dilution) 0.4 - 8 mg/L NH ₄ (with internal dilution) 2.5 - 100 mg/L NH ₄ (with internal dilution)
Rýchlosť prietoku vzorky:	100 - 300 mL/min
Teplota prostredia:	10 - 30 °C ± 4 °C deviation at 5 - 95% relative humidity (non-condensing)
Teplota vzorky:	10 - 30 °C
Trieda ochrany:	Protection class: Analyser cabinet: IP44 / Panel PC: IP65
Validation:	Automatic; frequency freely programmable
Vzorka: tlak:	By external overflow vessel
Záruka:	24 mesiacov
Zdroj napájania:	100 - 240 VAC, 50/60 Hz

Obsah balenia

EZ1102 Ammonium (Berthelot Method) Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets and 2 x empty 2.5L Glass Reagent Containers with Fittings (for Reagent A & Reagent B Solution)